# **Packing List**



Depending on the order, one of the two references is included.



### DT20

Glass

Solder-Collector.....1 set contains 2 pieces



#### **DT25**

Metal

Solder-Collector.....1 set contains 2 pieces



### DT20 / DT25 Solder-Collectors for DT530



Be careful when handling the solder collector and the other spare parts they can be hot. Let them cool down first.


**Note:** The pictures on the back show DT20, but all steps and descriptions are the same for DT25.







## DT20 / DT25 Replacement

To disassemble the solder-collector group, place the desoldering iron in horizontal position onto the stand, hold the tool with one hand down onto the stand (1), grasp the suction hose beside the protective cover (2) ...



... and pull upward (3) to undock the protective area.





Then undock the frontal gasket (4) from the heating element to disassemble the solder-collector group.

Replace the collector by disassembling and assembling the components in the shown order.

