Packing List

For ref. MS10:



Front Filter Set for MSE-B 1 set

(Each set includes 5 filters)

Manual 1 unit Ref. 0034152





MS10

Front Filter Set for MSE-B

MS10 filters are used with MSE-B.








www.jbctools.com




Filter Replacement

1. Sliding down the side tabs and open the front lid.




2. Remove the worn filter by pulling it upwards out of the snap-fits.




3. Position the new filter with its clear side upwards and with the cross-shaped strud at the left side.



4. Center the filter between the snap-fits and push it in.



5. Push the positioned filter back until it stops against the transparent ribs.



6. Close* the front lid by pressing against its both upper corners until it clicks.

